



The Fastest and Most Convenient

Stay ahead of the biofilm problem and eliminate having an empty chair, even if you fail a test. Easy-to-read results in just 15 minutes makes it possible to test after your last patient on any day, and be ready for your next patient the following morning. *FASTCheck15™* gives you control over your waterline safety in minutes, not days.

Be proactive about your waterlines instead of reactive. Passing more tests mean your staff can spend their time on what's most important to you... your patients.

Sterisil® SafeWater Testing Protocol

Stay ahead of biofilm by testing and shocking monthly.



Month 1

Test in-office with *FASTCheck15™*



Shock with Citrisil™



Month 2

Test in-office with *FASTCheck15™*



Shock with Citrisil™



Month 3

Mail-in test with *Sterisil® R2A™* Waterline test



Shock with Citrisil™



1-2-3 REPEAT for proactive waterline health



Scan to document results at:



my-solutions-center.solmetex.com

Failed test? It happens. Here's what to do:

Retest 5 days after shocking* If retest results fail, contact our experienced Customer Support specialists at **800-216-5505** or chat with a Water Specialist online at **Solmetex.com**

*Experts recommend waiting at least 5 days before retesting.

Testing Protocol FAQs

solmetex.com/failedtestprotocol



*CDC, OSAP, FDA, and ADA recommend documenting water monitoring results.

STERISIL PART #

SHELF LIFE

DESCRIPTION

FC15-6

2 YEARS

PACK OF 6 FASTCHECK15™ TEST STRIPS

Order/Info:

(800) 216-5505
Solmetex.com

SHOP NOW!
Bit.ly/fastcheck15-facts



Solmetex™
Dentistry's Complete
Provider of Water Solutions

Solmetex
Sterisil
DryShield